




ABC Gravotech SOFTWARE

QUICK START 2020



GRAVOTECH

E X P R E S S I O N O F T H I N G S

A. Legal notices

Last updated: 09/2020

The purpose of this document is to provide users (hereinafter the User(s)) with information and to ensure their safety. It has no contractual value and Gravotech group (hereinafter Gravotech) reserves the right, at any time and without notice, to make such changes or improvements as it deems fits, or to substitute any new equipment and/or material and/or part and/or image to its equipment, software and/or associated manuals or documentation (hereinafter the Product(s)).

This manual, including texts, images, photos, graphics, design, or any compilation, digital conversion or data contained in it, is subject to copyright. This manual shall not be reproduced, disseminated, transmitted, transcribed, translated or stored electronically, on any medium whatsoever regardless of its format without the express and written permission of Gravotech, to the exception of software backup copies as provided by law.

The intellectual property rights relating to the Products and to this manual, including - but not limited to - patents, trademarks, models, copyright, domain names and also the know-how, trading name or company name, are owned by Gravotech Marking S.A.S or any company of the Gravotech group. Under no circumstances does the transmission of this manual or the supply of Products or services constitute an assignment of or any express or tacit license for any intellectual property right owned by Gravotech.

To the extent permitted by law, Gravotech provides hereby no warranty (in particular no warranties of performance, non-infringement, merchantability or fitness for a particular purpose) relating to the supply of its Products, other than those conferred upon the User by Gravotech's general terms and conditions of sale or any contractual document agreed between Gravotech and the User. Nor does Gravotech guarantee the compatibility of its software with any software package not supplied by it, or any defect in assembly, adaptation, design, compatibility and operation with any or part of a combination created by the User.

Gravotech shall not be liable for any damages, that the User or its property, a third party or the Product itself may suffer, caused by the Product and arising from any inappropriate use or misuse of the Product, negligence, carelessness, inadequate supervision or maintenance, failure to observe the safety or usage instructions described herein or otherwise communicated to the User, the use of poor-quality or non-recommended lubricants, fluids and additives or where there is fault on the part of the User or a third party. As provided in this manual, the User shall furthermore (i) observe the normal conditions of use, (ii) not exceed the recommended maximum number of hours during which the equipment may be operated on and (iii) refrain from proceeding to any Product's repair or make it proceed by any unqualified third party, or without the appropriate personal protective equipment.

The Product's specifications are altered by (i) any Product's modification or alteration, (ii) any adaptation and installation of accessories that are not recommended by Gravotech, (iii) the integration of a control system and (iv) the connection to an external device. Such specifications' alterations may lead to the non-compliance of the Product with applicable rules and standards. Shall the Product be non-compliant, the person in charge of the Product's installation shall be responsible of the final workstation's compliance. In no event, Gravotech shall be liable for any damages arising from such non-recommended or unauthorized Product's alterations. It is precised that the warranty shall not apply in such case.

Under no circumstances shall Gravotech be held liable for any indirect, incidental, special, consequential punitive or other similar damages, including any economic loss, loss of profit, loss of data or opportunity, whether or not foreseeable by or communicated to Gravotech, caused by this manual or the supply of Products or services concerned by the said manual.

To the widest extent permitted by law, Gravotech shall only be held liable for direct damage arising from personal injury caused by a fault proven in its Product (including this manual).

Gravotech® and the trademarks of products marketed by Gravotech group are used, pending or registered trademarks of Gravotech Marking or one of Gravotech group subsidiaries.

The products and names of third party companies which appear in this manual are used solely for the necessary purposes of reference, and in particular for issues of compatibility. All the trademarks mentioned in this manual remain the property of their respective owners. Windows® is (are) a used, pending or registered trademark(s) of Microsoft Corporation. Postscript® is (are) a used, pending or registered trademark(s) of Adobe Systems Incorporated.

CONTENTS

Quick Start : Step by Step 4

 Toolbar : standard commands 9

 Settings : User Interface..... 11

 Add new Machine..... 13

 Adding a Gravotech machine as Bluetooth device..... 15

Material definition..... 17

 Rotative machining 19

Composition..... 21

Assign a machining path to selected text or shape 23

Machining..... 25


 WELASE settings 26

 M-series settings..... 31



Quick Start : Step by Step

1.  [Custom unit, language and computer that rule the program.](#)

2.  [Add the powered machine connected to PC/tablet.](#)


3.  [Select it as active machine](#)

4.  New document

5.  [Material definition](#)

6.  [Composition](#)

7.  [Machining](#)



Browse between A, B, C steps using arrows at the bottom of the main window



Some dialogs open to achieve an operation. When done, close window



Cancel operation



Validate operation



1 **Material definition**
[Set material size, orientation and origin](#)



2

Toolbar : standard commands

[Manage documents, actions or objects to machine](#)



3


Display virtual keyboard for tablet




4

Composition

[Add text, shapes or logos](#)




5 **Machining paths**
[Assign path to selected text or shape](#)



6 **Title bar**
Logo and Program version, Name of saved document, Buttons to Minimize and Close windows



Toolbar : standard commands



1 Settings



[Set user interface the first time the program starts.](#)

2 New document



Work from scratch

3 Open *.job file



Edit a saved document

4 Save document



Save it as JOB file

5 Undo



Cancel last action

6 Redo



Restore cancelled action

7 Zoom in/out



Double or reset material view

8 Select and edit text or shape



Resize or shift the selection.

9 Non-horizontal text



Set text slant



, vertical



, or along arc



10 Basic shapes



Draw a rectangle, a line




or a circle





Settings : User Interface



1 Select the current unit to measure distances and dimensions.



2 Select the current language to display program messages and dialogs.




3 Select the computer where program is set up.


mode pc

mode tablette

When the tablet is enabled, the program fits to tactile mode and a virtual keyboard gets available to type text.



4 Add new machine



[Select the powered machine connected to PC/Tablet.](#)

5 Validate



Back to main window




Add new Machine

Check that the machine has already been identified in Windows either as [a Bluetooth device](#) or through Ethernet or WIFI connection (refer to machine user manual).



Display the list of Gravotech machines



1 Scroll up or down the list.



2 Tick the connected machine.



Welase Fiber

3 At need, type your machine name.

Welase Fiber

4 Validate



At need, select the machine driver :

- Gravotech Laser for WELASE machines
- GT Smartstream for M-series machines



The new machine displays in the list of current machines.

Adding a Gravotech machine as Bluetooth device

 Power on the machine

 In Windows, open Control Panel 

In Windows 10

1. In Hardware and Sound, open Device and Printers
2. Add a device



3. Select the machine.




4.  Next


5. Enter the device's pairing code e.g. 1234



 In Windows 7

1. In Peripherals, open Bluetooth devices
2.  Add the machine
3. **Type the PIN code e.g. 1234**
4.  Connect





1 Set parameters and options below




Set material size, orientation and origin

2 Enable the active Machine



Select the powered machine connected to PC/Tablet. Parameters and options will fit the active machine.

3 Size the material inside machine area



4 Material Height




Set it when using any WELASE machine. This will raise or lower the material to fit in machine.

5 Orientation




Select normal (is default) or mirror  , 90°  or 180°  orientation.

6 Material origin according to the clamping accessory



Select the matching icon : Top left corner of table or Vice center


7 Origin coordinates




Top left corner is default at (0,0). Center is the machine area one.

When default values are edited, the origin gets floating and set by user. Arrows around icon confirm the floating status.

8 At need, shift the floating origin using arrow keys




9 Origin offset



View arrow shifting or key in value

10 Target the floating origin or bound the composition surface using arrow keys or Point&Shoot function



Enable red pointer and move it over material

11 Cylinder settings



[At need, configure rotative marking or ring engraving](#)

12 Composition




Add text, shapes or logos

13 Machining



Settings for M-series or WELASE machines



A. Set parameters, according to the item to machine

1 Flat material



Back to machining using table or vice

2 Cylinder or Pen



Key in the diameter and length



Key in the pen diameter for M-series machines

3 Inner ring



Key in the finger size or inner diameter, and engraving length



Select the type of jaws on M-series machines

4 Outer ring



Key in the perimeter or outer diameter, and engraving length



Select the type of jaws on M-series machines


B. Enable the rotation mode :



indexed (is default)




or combined



C. Key in the focal distance for laser marking



D. Validate



1 Composition



Add text, shapes or logos

2 Align text



Text lines are centred by default. Display text from the left or right end of baseline.

3 Shift text origin



Distance between the origin of the current baseline and the left border of material

4 Maximum text length



Distance between left and right ends of current baseline

5 Maximum text height



Distance between the current text baseline and the top side of the material

6 Text height



Distance between current baseline and top of the uppercase top

7 Switching to manual mode

Enable manual mode when you want to set text anywhere on material.



Manual mode will be automatically enabled when drawing shapes.
Go back to auto mode when text lines should be centred inside material surface.

8 **Text styles : Italics - Underlined - Exponent**



Select style before typing text or apply style to the selected text

9 **Gravograph fonts**



Select the font to type with



10 **True type fonts**



Select the font to type with



11 **Series of Logos**



Select the logo to insert



12 **List of available fonts and logos**



The name of the active font/logo displays by default.

13 **View the active font/logo**



Select the character to insert into text

14 **Material definition**




Set material size, orientation and origin

15 **Machining**



Settings for M-series or WELASE machines

3 **Contour cutting**



Vector cutting lines



4 **Surface raster**



Filling up a closed contour automatically



5 **Contour raster**



Filling up lines according to the thickness keyed in. Key in a Thickness higher than 0.1 mm.





Machining

[Assign a machining path to every object to machine \(filling, plotting, cutting\).](#)

Set machining properties



[Marking settings for WELASE machine](#)



[Engraving settings for M-series machine](#)



Connect the dongle allowing communication between the program and the machine

The GS dongle is the permanent protection key that manages data transfer from the program to the machine.

The dongle must be connected to a USB port on the PC before you can perform the following operations:

- sending a composition into machining
- simulation of a machining over the material
- positioning a block or plate by Point and Shoot




When the operation is triggered without the dongle, an error message signals the ban on access to the machine.

- A. End the operation on the machine
- B. Connect the dongle to a USB port on the PC
- C. Repeat from the program



WELASE settings



1 Set parameters and options below



Set values according to the technical features of machine. Refer to manual attached.

2 Active preset



Select the standard settings that match the material (and the machine).

3 Gravotech presets



Default settings per material (and per machine)

4 User presets




Saved settings specific to one material (and to one machine)

5 **Current machining settings**



6 **Machining paths assigned**

[Every path applied to objects in composition displays with the linked properties.](#)




7 **Power : Key in a value between 0 and 100%, proportionally to the power of laser source.**



8 **Speed : Key in a value between 0 and 100%, proportional to max. speed of machine motion system.**



- 9 Impulse rate : Key in a value between 5 and 200 KHz.**
The higher the frequency, the higher the number of shots per second.



- 10 Number of passes : Key in a number between 1 and 500.**
A pass equals one round of the laser beam to mark objects. Several passes can be required to gradually reach a given depth in some materials.




- 11 Defocusing : Key in a negative or positive distance.**
Lower or raise the material, before marking starts.



12 Wobbling

 Tick to enable the process. Common to thicken contour marking, this method makes the laser beam oscillate e.g. it marks in spiral the lines, according to a preset amplitude.

Compared to line plotting, wobbling does more readable text, when typed with filar characters, like those from Gravograph fonts.



13 Enabling wobbling will add two values.



14 Key in the wobbling diameter






15 Key in the gap between two contiguous circles



16 Key in the filling density i.e. number of lines/mm



17 Drive the sweeping mode



18 Cleaning pass



Enable this final pass to remove residue over marked surface

19 Machine connection



At need restart machine detection

20 Expert settings



Call out and configure Gravotech driver process



M-series settings



1 Set parameters and options below



Set values according to the technical features of machine. Refer to manual attached.


2 Active preset



material (and the machine)

Select the standard settings that match the

3 Gravotech presets



Default settings per material (and per machine)

4 User presets



Saved settings specific to one material (and to one machine)

5 **Current machining settings**



6 **Machining paths assigned**

[Every path applied to objects in composition displays with the linked properties.](#)



7 **XY speed : Key in a value between min. and max. speeds of the machine.**

Tool horizontal motion speed when marking material




8 **Z speed : Key in a value between min. and max. speeds of the machine.**

Tool drop speed when drilling material




9 Engraving depth : Key in a value matching the machining mode.

- To engrave using nose key in 0.02 and adjust engraving depth on machine.
- To engrave without nose key in a value between 0.01 and material thickness.



10 Z clearance : Set the tool raise between an engraved line and the next line to machine.



11 Spindle rotation : Enable the function when matching the machining mode.

- Diamond dragging excludes spindle rotation
- Engraving requires spindle rotation



12 Auto Z-ref : Tick the machining mode that calls out the function.

- Diamond dragging enables auto Zref.
- Engraving with nose enables auto Zref.
- Engraving without nose disables auto Zref.